

Sheridan Storage Reel





7100 Spectrum Lane ~ Missoula, Montana 59808 800.791.8056 ~ www.spectrumproducts.com

Sheridan Storage Reel Assembly Instruction



Product Number	Description
20061	5/16" Nylock Nut
20002	5/16" Flat Washer
20080	5/16" x 2 1/4" Hex Head Bolt
20023	1/2" Set Screw
47157	Caster
522800-03	Set Screw Bushing
522801-03	End Frame Bushing
522802-03	Wheel Hub Bushing

Reference the drawing on page 1 during assembly.

Verify you have received all parts necessary before assembly. Two persons may be required for the assembly process.

- 1. Attach the Horizontal Frame to the End Frame Assemblies using the hardware specified. Leave the hardware loose until the unit is fully assembled.
- 2. Attach the Captain's Wheels to the storage tube by aligning the holes and securing with the specified hardware.
- 3. Attach the Storage Tube Axle to the End Frames using the white plastic donuts with set screws.
- 4. Tighten all of the hardware through out the Storage Reel to insure a rigid product.

NOTE: Make sure the wheels are locked when the Storage Reel is being loaded.

The Importance of Proper Care and Cleaning:

In spite of high resistance to corrosion, the 304L stainless steel used in Spectrum products can be compromised in several ways. Iron-based rust can occur, regardless of the fact that being a nickel alloy, stainless steel does not ordinarily rust. This type of corrosion can happen by coming into contact with Halogen Salts (Chlorine and Bromine). Surface contamination and the formation of deposits are critical factors as well, which may lead to drastically reduced life of the product. Certain working environments can create more aggressive conditions, such as warm, high humid atmospheres above indoor swimming pools. These environments can increase the speed of corrosion, thus increasing the need for upkeep. Advice if often sought concerning the frequency of cleaning stainless steel surfaces, and the answer is quite simply "clean the metal when it is dirty in order to restore is original appearance". This time line could range from as often as once a day to as little as four times a year.

Cleaning, Care and Maintenance:

While the surface appearance of stainless steel products is attractive and hygienic, it cannot be regarded as completely maintenance free. All grades of stainless steel may in fact stain, discolor or attain an adhering layer of grime in normal service. To achieve the maximum corrosion resistance, the surface of the stainless steel must be kept clean. Providing cleaning schedules are carried out regularly, good performance and long life will be achieved. The cost and frequency to maintain the appearance of stainless steel is generally less in comparison to other materials. These costs often offset the higher initial costs associated with stainless steel products.

Spectrum Products® Cleaning Kit:

A technique known as passivation can be used to provide a chemically clean surface that will aid in the re-formation of the surface oxide layer. The oxide film forms naturally on clean surfaces exposed to the atmosphere, but contact with acid mixtures containing oxidizing agents can enhance its formation. An acid wash also serves the important function of dissolving any free-iron contamination on the surface of the stainless steel. Passivation is therefore recommended as a cleaning procedure to remove rust spots and free-iron deposits. Passivation is the removal of iron or iron compounds that build up on the surface of the stainless steel by means of a chemical dissolution. Periodic cleaning with Spectra-Clean TM

System 1, Spectrum Part Number 202050-00, is recommended for stainless steels that are used in commercial aquatic facilities.

The use of stainless steel in the manufacturing of swimming pool equipment has a long successful history. With an understanding of its care and maintenance it will provide you years of service.